



WILLIAM ROBERTS
— VINTAGE —

ASSEMBLY INSTRUCTIONS

PIPE AND WOOD SHOE RACK
PWSR

PIPE AND WOOD SHOE RACK ASSEMBLY INSTRUCTIONS



STEP 1 - LAY LONG SIDE OF WOOD SHELVES ON FLOOR

**STEP 2 - ALIGN FLANGE FITTINGS WITH PRE DRILLED HOLES ON SIDE OF SHELF
AND ATTACH ONE SCREW IN EACH SHELF**

STEP 3 - REPEAT ON OPPOSITE SIDE OF SHELVES

STEP 4 - GO BACK AND ATTACH REMAINING SCREWS IN EACH SHELF

STEP 5 - SCREW BASE ONTO EACH SIDE

LEVEL RACK IF NEEDED BY TIGHTENING OR LOOSENING FLANGE FITTINGS ON BOTTOM OF BASE.



WRV

**WILLIAM ROBERTS VINTAGE
10410 66TH STREET N UNIT #9
PINELLAS PARK, FL 33782**

INFO@WRVINTAGE.COM

PIPE & WOOD SHOE RACK

PWSR

(727) 902-7890

WRVINTAGE.COM